



REV 1.1

07/06/2023

OverWatch Periodic Inspection Checklist

DO001553

OVERWATCH PERIODIC INSPECTION CHECKLIST

It is recommended to complete an inspection of the EQSS OverWatch as part of the MEWP three monthly / periodic inspection. The goal is to confirm the OverWatch is correctly functioning and is undamaged.

This inspection is to be carried out by a competent technician who has the expertise and experience to safely operate the MEWP and evaluate the operation and condition of the OverWatch.

Item	Action	Notes	Pass / Fail
Visual inspection			
1.1	Conduct visual inspection <ul style="list-style-type: none">- Sensor is in position and clean- Wedge and brackets in correct position- Wires are connected and clamped	Refer to pre-hire checklist DO001152 visual inspection. Mounting positions and the use of angled wedges are different for each model. Check the model installation manual.	
Software			
2.1	Verify the software is current and update to the latest version	Goto www.eqss.com.au/overwatchsoftware	
Function assessment			
3.1	Complete the function assessment <ul style="list-style-type: none">- Indicator Light- Audio- Operator zone- Sensor Obstruction	Refer to pre-hire checklist DO001152 function assessment.	

Company:	Inspected by:
Date:	Signature: